



**\*\*PLEASE NOTE\*\***

I HAVE READ, UNDERSTAND AND APPROVE THIS DRAWING. THE INFORMATION AND DIMENSIONS AS STATED ARE CORRECT. THIS EQUIPMENT IS CUSTOM MADE AND NON-RETURNABLE.

SIGNED \_\_\_\_\_

DATE \_\_\_\_\_

**INSTALLATION NOTES**

***NOTE: PLEASE READ ALL INSTRUCTIONS PRIOR TO INSTALLATION.***

- DETERMINE THE SUPPORTING STRUCTURE IS ADEQUATE TO SUPPORT THE CRANE.**
- USE THE WALL BRACKET PATTERN SHOWN TO MARK AND DRILL THE BOLT HOLES IN THE SUPPORTING STRUCTURE. BE SURE BOTH HINGE PINS SHARE A COMMON TRUE VERTICAL CENTERLINE.  
USE MINIMUM GRADE 5 BOLTS AND NUTS (SUPPLIED BY OTHERS)  
USE BOLTS 1/16" LESS IN DIAMETER THAN THE BOLT HOLES.
- RAISE THE MAIN BOOM INTO POSITION AND BOLT THE HINGES TO THE SUPPORTING STRUCTURE.  
USE MINIMUM GRADE 5 BOLTS AND NUTS (SUPPLIED BY OTHERS)  
USE BOLTS 1/16" LESS IN DIAMETER THAN THE BOLT HOLES.
- INSTALL THE TELESCOPING BOOM BY REMOVING BOOM STOPS. SLIDE THE TELESCOPING BOOM ONTO THE MAIN BOOM AND REPLACE THE BOOM STOPS.
- INSTALL HOIST AND TROLLEY BY REMOVING TROLLEY STOPS. SLIDE THE TROLLEY ONTO THE TELESCOPING BOOM AND REPLACE THE TROLLEY STOPS.

MODEL NO.: ACA-72854  
 CAPACITY: 4000 LBS.  
 WEIGHT: 1535 LBS.  
 THRUST & PULL: 15350 LBS.  
 FINISH: CAT SAFETY YELLOW

- NOTES:
- HOIST NOT INCLUDED
  - NOT DESIGNED FOR OUTDOOR USE
  - NON-RETURNABLE PRODUCT

<b>C&amp;H DISTRIBUTORS</b> MILWAUKEE, WI		
DATE 4-25-06	NOT TO SCALE	BY WJ
<b>FULL CANTILEVER WALL MOUNT JIB WITH TELESCOPING BOOM</b>		